

VCRT

VALVE CORE REMOVAL TOOL™

Herramienta para quitar el núcleo de la válvula | Outil de dépose d'obus de valve



Valve Core Removal Tool

Herramienta para quitar el núcleo de la válvula | Outil de dépose d'obus de valve

1/4 in.

1/4 PULG. | 1/4 PO



Part# MGA VCT

Parte# MGA VCT | Partie# MGA VCT

5/16 in.

5/16 PULG. | 5/16 PO



Part# MGA VCR

Parte# MGA VCR | Partie# MGA VCR

✓ Removes Restrictive Valve Cores

Elimina los núcleos de válvula restrictivos
Élimine les noyaux de valve restrictifs

✓ 1/4 in. Side Port for Service Gauges

Puerto lateral de 1/4 pulg. para manómetros de servicio
Orifice latéral de 1/4 po pour manomètres de service

✓ Vacuum Rated to 20 Microns

Calificación de vacío de 20 micrones
Évalué sous vide à 20 microns

✓ Double O-Ring Seal

Sello de doble junta tórica
Joint torique double



Magnetic Base

Base magnética | Base magnétique

Adjustable Tip

Punta ajustable | Pointe réglable

Full Flow →
Flujo completo | Flux complet

No Flow →
Sin flujo | Pas de flux

